CUB5T PROGRAMMING QUICK OVERVIEW



Press and hold **SEL** key to enter Programming Mode.